



## Assembly

To prevent serious personal injury, death, or voiding the warranty, read warnings and instructions in the dock assembly instructions before attempting assembly or installation.

**DOCK SECTION** 

Place one 3/8 nut in each Connector Clip nut holder and thread the  $2-1/2 - 3/8 \times 1-1/4$  T-Handle through it just enough so that it does not fall out.

Attach two Connector Clips to each dock frame that will be supporting the Corner Frame. Place two 3/8 x 1.0 carriage bolts into the bottom slot of the dock on each side. Secure the connector clips to the dock using the carriage bolts and one 3/8 flange nut in each place - as shown.

Place the Corner Frame into the Connector Clips and tighten each 2-1/2 - 3/8 x 1-1/4 T-Handle against the Corner Frame until it is secure against the supporting dock frames.

Place Corner Panel in frame.