

Alum WAD Starter Kit (Pair)

Instructions

Part #: 1006599

Parts List			
ITEM	QTY	PART NUMBER	DESCRIPTION
1	2	1005725	WAD Starter Kit Wdmt
2	4	1001793	Nut Square 1/2 Brass
3	4	1001803	Nut Hex 3/8 Brass
4	4	1002432	Bolt Hex 3/8 x 3.0 SS
5	4	1002558	Set Screw 1/2 x 1.5 SS
6	8	1002599	Washer Flat 3/8 SS
7	2	1000984	Cap Blue 2.0x2.0x2.0 Five Sided

Failure to follow instructions may result in personal injury and may invalidate applicable warranty.

Step 1. Place one WAD Starter Pocket over each Side Rail of the dock where desired (6" from the end is recommended). Make sure the lip of the WAD Starter Pocket is over the bottom of edge of the rail and make a mark at each hole.

Step 2. Remove the WAD Starter Pockets and drill a 7/16" hole at each mark.

Step 3. Secure each WAD Starter Pocket to the dock with two 3/8 x 3 hex bolts, four 3/8 flat washers, and two 3/8 brass nuts - as shown.

Step 4. Insert the Leg Post/Foot Pad assembly into the WAD Starter Pocket to desired height and tighten with two 1/2 x 1-1/4 set screws and two 1/2 brass square nuts in each pocket - as shown.

Step 5. Place one Blue Cap over each exposed Leg Post - as shown.

