

Tow Hitch

Instructions

Part #: 1004501 - Bolt Bag Only

Part #: 1006658 - RS7 Dock Hitch Kit

Part #: 1006660 - TS9 Dock Hitch Kit

| Parts List | | | |
|------------|-----|-------------|--|
| ITEM | QTY | PART NUMBER | DESCRIPTION |
| 1 | 1 | 1004573 | Bolt Bag - Hitch |
| 2 | 6 | 1000876 | T Handle 3/8-16 x 1.5x2.5 w/ Cup Point |
| 3 | 1 | 1031565 | Coupler 2" For Tow Hitch |
| 4 | 4 | 1002599 | Washer Flat 3/8 SS |
| 5 | 2 | 1002432 | Bolt Hex 3/8-16 x 3.0 SS 304 |
| 6 | 2 | 1001803 | Nut Hex 3/8-16 Brass |
| 7 | 1 | 1003792 | RS-7 Tow Hitch Weldment |
| 7 | 1 | 1003793 | TS9 Tow Hitch Weldment |

Failure to follow instructions may result in personal injury and may invalidate the applicable warranty.

Step 1. Bolt coupler 2" to RS7 (or TS9) tow hitch weldment using 3/8 x 3 hex bolts, 3/8 flat washers and 3/8 brass nut.

Step 2. Thread T-handle bolts about a 1/2" into bottom of connector on RS-7 (or TS9) tow hitch weldment.

Step 3. Set tow hitch into channel on the top of the dock rail holding hitch up at about a 45 degree angle, then pivot hitch down and tighten T-handle bolts.

