

Motor Stop Straight Rack

Instructions

Part #: 1006968

Parts List			
ITEM	QTY	PART NUMBER	DESCRIPTION
1	2	1005719	Wdmt Motor Stop Leg Pocket
2	2	1002432	Hex Bolt - 3/8 - 16 x 3.0
3	2	1002424	Hex Bolt - 3/8 - 16 x 2.0
4	1	1005718	Assy Motor Stop Frame SM Adjustable
5	4	1001802	Nut Flange 3/8-16 Brass

Failure to follow instructions may result in personal injury and may invalidate the applicable warranty.

STEP 1

Attach the Motor Stop Arm to each Motor Stop Bracket. Secure with one 3/8 x 2 Hex Bolt and one 3/8 Brass Nut - as shown.

STEP 2

Center the Motor Stop Brackets on the Rack Beam. Secure each Bracket with two 3/8 x 3-1/4 Hex Bolts two 3/8 Flat Washers and two 3/8 Brass Flange Nuts - as shown.

STEP 3

Adjust the Motor Stop Arm to the desired position and tighten all hardware.

