

8" PolyDock Plastic Cleat

Instructions

Part #: 1017221

Parts List			
ITEM	QTY	PART NUMBER	DESCRIPTION
1	1	1001089	Cleat 8.0 Plastic
--	1	1006548	Bolt Bag Poly Dock Cleat 8 Inch
2	2	1000505	Screw Flat Allen 3/8-16 x 2.25 SS

Failure to follow instructions may result in personal injury and may invalidate the applicable warranty.

Step 1. Locate threaded steel inserts on poly dock. (Installed from factory)

Step 2. Place the cleat over the threaded inserts on dock.

Step 3. Insert 3/8 x 2-1/4 allen screws through cleat and tighten into threaded inserts.

