

## Wheel/Axle Adapter for 2 x 2 Dock Legs

### Instructions

Part #: 1006709

Parts List			
ITEM	QTY	PART NUMBER	DESCRIPTION
1	1	1003800	Wheel Kit Coupler Bracket
2	1	1002558	Set Screw 1/2 x 1.5 Square Head
3	1	1001793	Nut Square 1/2
4	2	1001763	Washer Large
5	1	1002569	Cotter Pin .25 x 2.5

Failure to follow instructions may result in personal injury and may invalidate the applicable warranty.

**Step 1.** Insert the Dock Leg into the Wheel Kit Coupler Bracket and secure with one 1/2 x 1-1/2 Set Screw and one 1/2 Square Nut - as shown.

**Step 2.** Slide one large washer onto the axle, then the Poly Tire followed by one large washer. Secure with one 1/4 x 2-1/2 cotter pin - as shown.

